

Flex Counter Standard



Use

The Flex Counter can be used for multiple purposes e.g. speed measurement, area-, rotation- and wrap counting. The Flex Counter is easy to mount. No power cable is needed as the Flex Counter is battery driven.

Functions

- F.1 Measures speed
- F.2 Partial and total area
- F.3 Unit counter
- F.4 Rotation counter and rotation time
- F.5 Working hour (start/stop)
- F.6 Wrap counter with alarm

The Flex Counter measures only one of the functions stated above at the time. If more functions are to be monitored simultaneously, we recommend the PX Combi 800 Series.

Installation

The monitor is installed in the cabin with the fittings included. Installation guidelines for magnet and sensor are included.

Technical specifications

Size:	114 x 72 x 33 mm
Weight:	150 grams
Display:	4 digits
Batteries:	2 x 1.5 V (AA)

Ordering number

001-2-0001 Flex Counter includes:
1 monitor w/sound
1 pcs. mounting kit for monitor
1 pcs. reed sensor with 5,0 m cable
2 pcs. batteries 1.5 V (AA)
1 mounting kit for sensor/magnet

Guarantee

1 year guarantee from date of delivery.