

Flex Counter - with tank counter



Use

The Flex Counter can be used for multiple purposes e.g. speed measurement, area-, rotation- and wrap counting. The Flex Counter is easy to mount. No power cable is needed, as the Flex Counter is battery driven.

In addition the tank counter also counts loads.

Functions

- F.1 Measures speed
- F.2 Partial and total area
- F.3 Unit counter
- F.3.2 Load counter / Accumulates the total volume m² (integrated alarm)
- F.4 Rotation counter and rotation time
- F.5 Working hour (start/stop)
- F.6 Wrap counter with alarm

The Flex Counter measures only one of the functions stated above at the time. If more functions are to be monitored simultaneously, we recommend the PX Combi 800 Series.

Installation

The monitor is installed in the cabin with the fittings included. Installation guidelines for magnets and sensors are included.

Technical specifications

Size:	114 x 72 x 33 mm
Weight:	150 grams
Display:	4 digits
Batteries:	2 x 1.5 V (AA)

Ordering number

001-2-0006 Tank Counter includes:
1 monitor w/sound
1 pcs. mounting kit for monitor
1 pcs. double reed sensor with 5.0 m cable
2 pcs. magnets (20 x Ø 4.3 x 10 mm)
1 mounting kit for sensors/magnets
2 pcs. batteries 1.5 V (AA)

Guarantee

1 year guarantee from date of delivery.